



Application Instructions

General

Coating Type: Air cure, one part, factory blended

Description: High Reflectivity, Temperature Resistant (550 °C)

Features and Benefits: Room temperature air cure formula, no catalyst required

Color: Silver

Dry Film Thickness: ~ 0.8-1.2 mil (20-30 microns) Spraying more than recommended thickness does not improve coating performance.

Cure Time

Dry to Touch: 30-50 minRecoat: 2 hours (if needed)

• Full Cure: 7 days (allow 20 days before cleaning with harsh solvents)

Precautions

- Do not dilute, this coating is formulated to be sprayed as is using HVLP gravity fed gun
- Do not heat cure
- Do not repackage
- Storage Temperature: Between 40- 80 °F (4-27 °C)
- Apply coating when air and surface temperatures are between 60-80°F (15-27 °C) and relative humidity between 30-80%.
- Cooler temperatures or higher humidity may prolong drying and tack free time.
- Wait three weeks before cleaning the coated part with solvents

Substrate & Surface

This coating can be applied to steel, glass, aluminum, some ceramics, some plastics, or primed surfaces.

Metallic Substrates Preparation

All surfaces must be clean, sound, dry, and free of any dirt, grease and other contamination. You can degrease with solvents such as xylenes.





Application Instructions

Blast the metal surfaces to remove any rust, scale, or other contaminants. The blasted texture is necessary for maximum adhesion. We recommend using clean and dry 46 to 100 grit aluminum oxide or alternative material.

Do not use oily or contaminated blasting media. After blasting, do not touch any surfaces with bare skin or contaminated gloves where coating will be applied. Blow off the substrates using compressed air. Ensure the air supply is filtered from moisture and oil. Make sure that there is no residue left on the surface. Clean the surface with a solvent such as xylenes, if needed. Safety goggles or a face shield are recommended. Work in a well-ventilated area or wear a respirator.

*Important: The surface must be cleaned after blasting to remove contaminates that can interfere with coating appearance and performance.

For best results place substrate in oven at 150 C/ 300 F for 30 minutes and allow it to cool to room temperature before spraying.

Other Surfaces

Careful surface preparation is essential for the maximum performance of this material. Remove grease and other surface contaminants with a degreasing process. For example, use a degreasing solvent such as xylenes. Wipe the surface with the degreaser using a clean cloth followed by dry cloth wipe. Repeat this process several times until the drying cloth does not pick any dirt (color from the surface). Make sure to use clean, soft, absorbent, lint-free cloths and DO NOT dip the cloth into the solvent container.

Mixing and Thinning

Mixing

Mix the InfernoWare Reflect until no solids remain at the bottom of the container and the product is completely mixed. Incomplete mixing or insufficient dispersion of the solids may result in product failure. Do not dilute, the product is ready to use. *TRC-2* will require at least 5 minutes of agitation.





Application Instructions

Storage

Store between 40-80 °F (4-27 °C) in a dry and well-ventilated area. Keep container clearly labeled and tightly closed. Avoid contact with water. Opened containers must be carefully resealed and kept upright to prevent leakage. Keep away from heat, flames, static electricity. Containers are hazardous when empty as they contain product residues.

TRC-2: Bottles may be under pressure, please open slowly pointing bottle away from you.

Thinning (Dilution)

Do not thin. Thinning might result in a change of coating performance.

Application Guide

Preparation

Do not touch any surfaces with bare skin where coating will be applied. Only use clean gloves, such as nitrile or powder-free latex.

Arrange parts for the best access with the spray gun. Ensure the spray gun's air supply is filtered from moisture and oil.

Filter the desired quantity of coating through a 30 mesh strainer into spray gun.

Spraying

In the case of using a small spray gun like IWATA LPH-80 or similar:

Apply the coating with an HVLP gravity fed gun with a 1.2 mm fluid nozzle. Pigment is too big to flow through a smaller fluid nozzle. The air pressure should be set to 25 PSI with the trigger depressed, resulting in an approximately 3-4" fan pattern. Spray from approximately 3-4 inches from the substrate until the surface is covered. Overlap subsequent passes by 90%, continuing to apply new coating while the previously applied pass is still wet. Spray with sufficient volume so the InfernoWare Reflect does not dry spray, which is when the coating dries in the air before reaching the part. If second coating is needed, allow coating to dry for at least 2 hours at room temperature before applying the second coating using the same parameters listed above.





Application Instructions

Coating parameters may need to be adjusted by experience to account for specific spray gun setups and application area airflow. For large substrates, you can use a gun with a larger fluid nozzle and adjust all parameters accordingly.

Spraying a practice part is always recommended for initial spray gun setup.

*Important: When spraying on plastics, test on a sample of the plastic first to check for color/texture and adhesion. The product will have very strong adhesion to certain plastics. Once applied to (including but not limited to: ABS...) it will be very hard to remove.

Spraying more than 1 mil thickness does not improve coating performance.

Allow the parts to air dry (do not oven cure). Use caution to avoid touching the coating while it is curing. The parts will be tack-free after 30-50 minutes at room temperature and can be handled and packaged after 1 day.

Please note that low temperatures or higher humidity may prolong drying and tack free time.

Handling After Spraying

Wait 3 weeks before cleaning

avoid harsh solvents, such as acetone

Refer to product SDS for proper handling, disposal, cautions while using. Please contact InfernoWare *info@infernoware.net* if you have any question concerning use and application.

DISCLAIMER: The information in this Product Application Guide is believed to be correct as of the date issued. InfernoWare provides information in electronic form as a service to its customers. Due to the remote possibility that electronic transfer may have resulted in errors, omissions, or alterations in this information, InfernoWare makes no representations as to its completeness or accuracy.